

Pump Service & Engineering Ltd

Waste Water & Sewage Pump Service Guide

www.pumpserviceltd.com

Preventative Maintenance – The key for reliability!



- 1) Lift Pump(s), clean and check data plates for info.
- 2) Check pump for wear/damage.
- 3) Check impeller condition and unblock if required.
- 4) Check wear rings.
- 5) Test motor electrically and mechanically.
- 6) Check oil for water ingress.
- 7) Check cable & glands.
- 8) Check float switches.
- 9) Check pipework and guide rails.
- 10) Check operation of control panel.
- 11) Check alarms.
- 12) Clean down chamber and clear any obstructions.
- 13) Reinstall pump(s)
- 14) Check operation of pumps and float switches on completion.
- 15) Provide condition report.



Any parts or further work required would be charged extra to the standard service price.

**Unit 17 Charlestown Ind Estate, Robinson Street, Ashton-Under-Lyne. OL6 8NS.
Tel. 0161 330 3875 Fax. 0161 330 5024 e-mail . enquiries@pumpserviceltd.com**